




# ВЕНЕТО







## Стол рабочий с ящиками











### СТЛ.266.15

#### Assembly instructions




№	Размеры	Кол.	Пакет
1	540x752x38	1	Пакет 1
2	540x752x38	1	Пакет 1
3	615x461x16	1	Пакет 1
4	560x80x16	1	Пакет 1
5	538x150x38	1	Пакет 1
6	380x461x16	1	Пакет 1
7	398x461x16	1	Пакет 1
8	588x392x3	1	Пакет 1
9	1186x536x32	1	Пакет 2
10	1186x220x16	1	Пакет 2
11	392x256x16	1	Пакет 3
12	392x154x16	1	Пакет 3
13	392x170x16	1	Пакет 2
14	354x303x3	3	Пакет 1
15	300x160x16	1	Пакет 2
16	300x160x16	1	Пакет 2
17	340x147x16	1	Пакет 2
18	300x114x16	2	Пакет 2
19	300x114x16	2	Пакет 2
20	340x101x16	2	Пакет 1

0100 	0063  M4x25	0200  Ø8	0201  Ø5	0010  5x40	0083  L = 300mm
8шт.	6шт.	4шт.	4шт.	2шт.	3шт.

0059 	0032  4x13	0009  7x50	0009 	0022 	0020 	0022 	0045  Ø8x30mm	0047  Ø8x50 mm	0184  арт.РА375
21шт.	18шт.	6шт.	6шт.	28шт.	28шт.	28шт.	38шт.	12шт.	3шт.

1






п.3


0047

3



п.4

4



п.5

0009

0045

порядок  
установки ящика  
на направляющие.

